

SLC TWIN RT²

QUICK START GUIDE

- SLC 700 TWIN RT2
- SLC 1000 TWIN RT2
- SLC 1500 TWIN RT2
- SLC 2000 TWIN RT2
- SLC 3000 TWIN RT2




1

SAFETY


www.salicru.com/safety

2

1x [A] 3x [B] 1x [C] 2x [E] 2x [F] 8x [Screws] 1x [QUICK START GUIDE] 1x [WARRANTY]



DOWNLOADABLE SOFTWARE:
www.salicru.com/support



USBHID UPS



USER'S GUIDE:
www.salicru.com/support

